






# INTERFACE USB pour FLUKE HP8920A

Bertrand, Électro-Bidouilleur



NOTE:  
Arduino-Nano Must be modified to receive Vin pin supply instead of USB supply: Remove Schottky diode.

MOUNTING HOLES



NOTES:  
+15V AND -15V SUPPLIED BY FLUKE 8920A'S J501 CONNECTOR.  
+5V SUPPLIED BY ARDUINO NANO'S ONBOARD VOLTAGE REGULATOR.  
+5V\_ANALOG PRODUCED ONBOARD, OFF OF +15V.

## VERSION 1.0

Sheet: /  
File: HP8920A\_Interface\_v1.sch

Title:

Size: A4 Date:  
KiCad E.D.A. kicad 5.1.5-52549c584ubuntu18.04.1

Rev:  
Id: 1/1