

Advantest R6144 Faulty Output

Volt Setting	1.6V Range	160mV Range	16mV Range
16	1.5992	4.981	4.836
15	0.2957	4.917	4.843
14	0.6242	4.997	4.850
13	0.9527	4.924	4.857
12	1.2812	5.013	4.865
11	1.6096	4.932	4.872
10	0.3061	5.028	4.880
9	0.6346	4.942	4.888
8	0.9630	5.043	4.896
7	1.2915	4.953	4.904
6	1.6199	4.914	4.912
5	0.3164	4.966	4.919
4	0.6447	4.916	4.927
3	0.9734	4.979	4.697
2	1.3019	4.920	3.955
1	-1.5980	4.994	3.212
0	0.3268	4.924	2.469

