



N/A means component is Not Assembled.
 *Component values only applicable when AD9951 is used.
 *² C27 and C28 installed only when REF CLK input used. In that case Q1, C20 and C21 not installed. SJ1 shall be configured accordingly.